


TRUST SUPER TUNING SYSTEMS AIMED AT REAL COMPETITORS



Please read this manual and completely understand the manual before using this product.

**TRUST**



## 1. Important Information

Please read this instruction manual carefully, and proceed with the installation ONLY if you fully understand this manual. Make sure to pay attention to all the "Important!" "Warning!" and "Caution!" messages through out the manual.

### **IMPORTANT!**

- This product is legal for sale or use in California only on vehicles which may never be driven on a public highway.
- This product is only for vehicles with 12V (battery) systems.

### **WARNING!**

- Installation and use of this product should only be performed by a trained specialist, who is very familiar with the automobile's mechanical, electrical, and fuel management systems. If installed by untrained person, it may cause damage to the unit as well as the vehicle.
- When using a soldering iron or other tools for installation, make sure you read and understand the tool's user manual. Mis-use of these tools can cause serious injuries.
- Never tune the E-Manager while the vehicle is moving.
- Never tune the e-Manager on public highways. This can be dangerous to you and others on the road.
- When tuning and operating the vehicle in a garage, make sure that the garage is equipped with a proper ventilation system.
- After installation and tuning, make sure to clean up every thing that would interfere the driver. Wires, tools, and laptop computer may interfere with the driver and cause accidents.
- Avoid open sparks, flames, or operation of electrical device near flammable substances.
- Make sure there are no leaks in the fuel system and that all of the connections are secure.



## 11. About maps and Setting

### Auxiliary Output Setting

- This map can be used to control VTEC or for O2 Sensor Adapter (to control the O2 sensor feed back feature to force the system to go in to "open loop")
- In the "ON" area the system will output 12V signal. This is when the e-manage will send a signal to activate the VTEC.
- Airflow adjustment can be made while in "ON" area. This will be the fuel compensation when the Vtec shift points are changed.

### (How to set)

- Click on the cells to turn "ON" and "OFF" in the corresponding load and rpm points.
- Input the airflow adjustment value.

RPM: rpm  
 Input range: 500~1600rpm, 50 rpm  
 Adj. value: %  
 Input range: -20~20%, 1% increment

### NVCS Setting

- This map is used to control the NVCS (Nissan Valve Control System)
- In the "ON" area the system will ground the connected signal channel.

### (How to set)

- Click on the cells to turn "ON" and "OFF" in the corresponding load and rpm points.

RPM: rpm  
 Input range: 500~1600rpm, 50 rpm

## 2. Parts List

Please

- Please confirm that you receive all the parts listed below. If there are anything missing, please contact your Greddy Authorized Dealer.




Main Unit x1



CD-ROM x1



Allen Wrench x1



Operation Manual  
x1



Installation Manual  
x1



Warranty Card x1  
(Japan use only)

### 3. Product Features

#### Each maps and settings

##### Airflow Adjustment

- Airflow Adjustment Map : This map is used to adjust the airflow sensor signal to the ecu for fuel enrichment.
- Airflow Output Map : This map is used when eliminating the airflow meter to feed airflow signal to the ECU by inputting the actual voltage or frequency in the map.
- Boost Limiter Cut Setting : This map is used to eliminate the factory boost limiter.
- Anti Engine Stall Setting : This map is used to prevent engine stall caused by blow back to the airflow meter.

##### Injector Adjustment

- Injector Adjustment Map 1&2 : This map is used to adjust the injector signal to trim and add fuel.
- Acceleration I/J Adjustment Map : This map is used to fine tune the fuel enrichment during acceleration.
- Individual Cylinder I/J Adj. Map : This map is used to fine tune each cylinder.
- A/F Target Map : This map can automatically set the I/J Adj. Map to meet the inputted Air/fuel ratio.
- Vehicle Speed Adj. Map : This map can be used to fine tune the fuel enrichment at different speed.
- Water Temp Adj. Map : This map can be used to fine tune the fuel enrichment at different coolant temp.
- Intake Temp Adj. Map : This map can be used to fine tune the fuel enrichment at different Intake temp.
- Rev Limiter Cut Setting : This map can be used to change the factory rev limiter.

##### Ignition Adjustment

- Ignition Adjustment Map 1&2: This map is used to adjust the ignition timing.
- Acceleration IGN Adj. Map : This map is used to fine tune the ignition timing during acceleration.
- Individual Cylinder IGN Adj. Map : This map is used to fine tune each cylinder.
- Ignition Cut Setting : This feature is used to activate an ignition cut at desired rpm.
- A/T Shift Adj. Setting : This feature can be used to adjust the ignition timing to prevent knock during shift up and shift down.

### 11. About Maps and Setting

#### Individual Cylinder Injector Adjustment Map

- This map can adjust the ignition timing of each ignition channels.
- This map should be tuned only by a person who is experienced engine management tuner with a proper testing equipments.

##### (How to set)

- Input the ignition timing adjustment value for each channel.

	500	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000	7500	8000
1	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
3	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
5	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
6	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Adjustment value: °

Input range: -20~20°, 0.5° increment



## 5. Software Install / Driver Install

### Software Installation Procedure

1. Turn the PC "ON"
2. Insert the CD-ROM in to CD-ROM drive. This Software will start the auto install. Follow the on screen instruction.
3. When the installation is complete there will be a short cut on the desktop. Click on this icon to start the program.



This installation will create a "TRUST" folder in the Programs File in C drive.

### Important

- If the auto install does not run automatically, manually install the software by double clicking on the "setup.exe" file in the CD-ROM.
- If there are any problems with running the program or communication, please uninstall the software and reinstall.

### Software Uninstall Procedure

1. Open the "Control Panel" and click on "Add or Remove Program".
2. Select "GReddy e-manage Ultimate" in the "Currently Installed Programs" and click on "Change/Remove"
3. Follow the on screen instructions.

### Driver Install Procedure

- After the software is installed, and when the GReddy e-manage Ultimate is connected to PC with a standard USB cable (available at any computer supply stores), the system will automatically detect the e-Manage2 USB. Hardware Wizard will start the installation procedure automatically. Follow the on screen instructions.
- The driver is installed at the time of the software install. Driver folder is located in The GReddy e-manage Ultimate folder in TRUST folder located in Programs File.

C:\Program Files\TRUST\GReddy e-manage Ultimate\driver

## 11. About Maps and Setting

### Ignition Adjustment Map 1 & 2

- This map is used to adjust the factory ignition timing.
- Input "0" for factory ignition timing.
- Input negative number to retard and positive number to advance the factory ignition timing.

#### (How to set)

- Input ignition timing adjustment value in the corresponding load and rpm points.

Adjustment value: °  
Input range: -20~20°, 0.5° increment

### IMPORTANT

- The values inputted in this map are not the actual ignition timing, they are adjustment values.
- When inputting adjustment values, make sure to monitor proper engine conditions.

## 11. About Maps and Setting

### Sub Injector Map

- This map is used to control the sub injectors.
- The input value can be set for injector duty cycle or duration.
- The sub injector channels must be configured in the "I/J" setting in the Parameter.

#### (How to set)


Input the sub injector duty cycle or duration to the corresponding load and rpm points.

Airflow Hot Wire(V)	500	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000	7500	8000
2.00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2.20	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2.40	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2.60	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2.80	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
3.00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
3.20	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
3.40	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
3.60	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
3.80	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4.00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4.20	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4.40	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4.60	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4.80	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
5.00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Duty cycle : %  
 Input range: 0~100%, 0.5% increment  
 Duration: ms  
 Input range: 0~20ms, 0.02ms increment

## 6. Operation Flow Chart



Please read!



## 7. Connecting to Main Unit

### Start the Application

1. Turn the IG key to "OFF" position, then connect the USB (A-B) cable to pc and e-manage Ultimate.
2. Turn the IG key to "ON" position and double click on the "e-manage Ultimate" sort cut. The following windows will appear on the screen.



Please

- Please make sure to use USB1.1 compatible cable.

## 11. About Maps and Setting



### Rev Limiter Cut Setting

- This feature can be used to change the factory rev limit on engines that cuts fuel to regulate the rev limit.
- Set the fuel cut activation throttle position value for the e-manage to recognize the throttle off condition. When the e-manage Ultimate detect the throttle off condition, the fuel cut will activate to prevent blowing flame out the tail pipe.
- This feature will not work on engines which cuts the ignition to regulate rev limit.

#### (How to set)

- Record the Injector duty cycle or duration, and rpm of when the fuel cut occurs.
- Input the rpm right before the fuel cut actually occurs in the "Hold" rpm.
- Input the new rev limit rpm to the "Limit" rpm.
- Input the injector duty cycle or duration for the corresponding load, "Hold" and "Limit" rpm points. Make sure to monitor a reliable A/F meter to make this adjustment.
- Input the fuel cut activation throttle position value.
- Input the Hold Time to ensure factory rev cut hold.

Example: Factory rev limit is 7000rpm, new rev "Limit" is 9000rpm. "Hold" rpm will be 6800rpm.  
Factory fuel cut signal last for 1.0ms, so the hold time needs to be over 10ms to ensure the cut hold.



- T.P value: %  
Input range: 0~10%, 1% increment
- Hold Time: ms  
Input range: 0~5.0ms, 0.1ms increment
- RPM: rpm  
Input range: 5000~10000rpm, 50 rpm
- Duty cycle: %  
Input range: 0~100%, 0.5% increment
- Duration: ms  
Input range: 0~20ms, 0.02ms increment

## 11. About the Maps and Setting

### Vehicle Speed Adjustment Map

- This map is used for vehicle speed fuel compensation.

#### (How to set)

- Input the injector duty cycle or duration value for the corresponding vehicle speed and rpm points.

	0.0	2.0	4.0	6.0	8.0	10.0	12.0	14.0	16.0	18.0	20.0	22.0	24.0	26.0	28.0
2800	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2700	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2600	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2500	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2400	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2300	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2200	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2100	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2000	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Vehicle Speed: km/h  
Input range: 0~400km/h, 10 increment

### Water Temp Adjustment Map

- This map is used for water (coolant) temp fuel compensation.

#### (How to set)

- Input the injector duty or duration value for the corresponding water temp and rpm points.

	0	8	16	24	32	40	48	56	64	72	80	88	96	104	112
2800	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2700	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2600	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2500	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2400	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2300	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2200	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2100	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2000	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Temp: °C  
Input range: -20~120°C, 1° increment  
Adjustment Value: %  
Input range: -20~20%, 0.5% increment  
Adjustment Duration: ms  
Input range: -4~4ms, 0.02ms increment

### Intake Temp Adjustment Map

- This map is used for intake air temp fuel compensation.

#### (How to set)

- Input the injector duty or duration value for the corresponding intake air temp and rpm points.

	0	8	16	24	32	40	48	56	64	72	80	88	96	104	112
2800	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2700	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2600	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2500	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2400	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2300	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2200	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2100	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2000	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Temp: °C  
Input range: -20~120°C, 1° increment  
Adjustment Value: %  
Input range: -20~20%, 0.5% increment  
Adjustment Duration: ms  
Input range: -4~4ms, 0.02ms increment

## 7. Connecting to Main Unit



### Main Unit Update

- When the e-manage Ultimate is connected to PC, and if there are newer version of firmware on the PC, the system will automatically check the unit and show the window shown below. Click "OK" to update.



- \*If the e-manage Ultimate is programmed with the same version as the PC, this will not appear.

- Select the update file "gsc02.p" and the system will automatically update the unit. Download will take approximately 1 minute.



### Please

- While communicating, please do not turn of the ignition "OFF" or disconnect the USB cable. This can damage the unit and will cause irratic operation.

## 7. Connecting to Main Unit

3. After the update is complete, message shown below will appear. Click on “OK” and turn the ignition key “OFF”, and wait couple seconds before turning back “ON”.




4. Confirm the update in the version information window in the “HELP(H)” pull down menu. If the F/W version matches with the update file update is complete.



### To manually update

For any reason, if the update failed, update the unit manually by selecting “Main Unit Update” in the “Communication” pull down menu.



- \* The update file “gsc02.p” is located in the “e-manage Ultimate” folder which is located in the “TRUST” folder in the “Programs Folder”. When downloading new updates, make sure that the “gsc02.p” file is in the “e-manage Ultimate” folder. If the latest update files are not in this folder, the system cannot check the newest version information, and auto update cannot be performed.

## 11. About Maps and Setting

### A/F Target Map

- This map is used to automatically program the selected map (in the “A/F Target” section in the parameter) with the inputted A/F values.
- This feature will monitor the A/F sensor that is connected to the “OPTION” port and configured in the “Front Panel” and make the proper adjustment to the selected map to achieve the inputted air/fuel ratio.

### (How to set)

- Input the A/F target value for the corresponding load and rpm points.

- \* Be sure to input “-” in the area where factory ecu is in the closed loop (ecu monitoring and correcting by monitoring the factory O2 sensor signal).
- \* While the ecu is in closed loop, ecu will continuously adjust the ari/fuel ratio between 14~15. During this time, A/F Target map feature will not function properly since the ecu is making adjustments.
- \* To force the ecu to go in to Open Loop, “Auxiliary Output Map” can be used.

	500	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000	7500	8000
400	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
500	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
600	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
700	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
800	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
900	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
1000	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
1100	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
1200	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
1300	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
1400	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
1500	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
1600	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
1700	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
1800	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
1900	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
2000	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
2100	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
2200	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
2300	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
2400	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
2500	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
2600	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
2700	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
2800	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
2900	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
3000	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
3100	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
3200	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
3300	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
3400	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
3500	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
3600	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
3700	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
3800	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
3900	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
4000	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
4100	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
4200	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
4300	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
4400	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
4500	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
4600	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
4700	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
4800	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
4900	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
5000	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
5100	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
5200	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
5300	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
5400	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
5500	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
5600	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
5700	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
5800	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
5900	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
6000	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
6100	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
6200	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
6300	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
6400	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
6500	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
6600	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
6700	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
6800	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
6900	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
7000	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
7100	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
7200	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
7300	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
7400	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
7500	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
7600	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
7700	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
7800	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
7900	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
8000	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

A/F  
Input range: 10~18, 0.1 increment.

### IMPORTANT

- To use A/F Target Map, A/F ratio meter will an external output signal channel is required

### CAUTION

- If A/F Target feature is activated in the area where the factory ecu is in the closed loop, the A/F Target map will input improper values to the selected map.

## 11. About Maps and Setting

### Individual Cylinder Injector Adjustment Map

- This map can adjust the injector duty cycle or duration of each injector channels.
- This map should be tuned only by monitoring each individual cylinders a/f ratio.

#### (How to set)

- Input the Injector duty cycle or duration adjustment value for each channel.

	500	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000	7500	8000	8500	9000
1	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
3	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
5	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
6	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
7																		
8																		

Adjustment rate: %

Input range: -10 ~ 10%, 0.5% increment

Adjustment duration: ms

Input range: -2 ~ 2ms, 0.02ms increment

## 8. Parameter Setting

Please Setup

### Parameter Setting

- By selecting the vehicle's engine code, the system will set up other setting in the parameter tabs for the specific application, and will make it possible to start the engine.
- If any of the sensors are changed, necessary parameters is required to be adjusted. Follow the instructions for the appropriate parameter tabs.
- If any features were added or removed, necessary parameters is required to be adjusted. Follow the instructions for the appropriate parameter tabs.

Open the "Parameter Setting" window by clicking the parameter icon shown below.



Parameter Icon



Parameter Setting

IGN | Trace | Map Select | Main Logger | A/T Shift

Vehicle | Throttle | CH Setting | Front Panel | A/F Target | I/O

Engine Code: [Dropdown]

# of Cylinders: [Dropdown]

Engine Size: [Text: 0]

Airflow Meter Type: [Text]

Airflow Meter Spec: [Text]

Airflow change to: [Text]

RPM Signal Type: [Dropdown]

Crank Angle Type: [Text]

Oil Set Angle: [Text: 0.0]

Vehicle Speed Pk: [Dropdown]

Vehicle Speed Adk: [Text: 1] %

Speed Limiter Cut:  Activate  Deactivate

OK | Cancel | Apply

## 8. Parameter Setting

Please Setup

### Vehicle Type

- This section is used to setup the e-manage Ultimate for the application it is being used on.
- By Selecting the Engine Code, the system will automatically set the sensor types, but when some of the sensors are changed or upgraded, this feature can be used to make any necessary changes.

Select the engine type

Number of cylinders can be changed for different application.

Displacement can be changed for different application

Shows the engine's airflow metering type.

Shows the airflow spec

Used when changing the airflow meter. Select the new airflow meter type.

Select how the rpm signal will be monitored.  
\* Most of the applications will be from RPM signal (ECU Tach signal)

This is automatically set when the engine type is selected.

This is used to correct any differences in the displayed ignition timing and the actual timing.  
\*Example: If the actual ignition timing is 15° and the data log display 13° enter "2" to offset the value.

Vehicle Speed Pulse value will display.

Used to correct the vehicle speed signal from different tire size or final gear.

Speed Limiter Cut  
 Activate  Deactivate

This feature is used to eliminate the factory speed limiter.

- This feature will not work on vehicles without vehicle speed signal.
- This feature may not work on some vehicles.

## 11. About Maps and Setting

### Injector Adjustment Map 1 & 2

- This map is used to add or trim the factory injector fuel injection by altering the factory injector signal.
- The "0" within the maps are factory ecu setting (no adjustment made).
- By configuring the injector input channels and making the proper wiring and jumper setting, this Map can be used to "Add & Trim" or "Add" only.

#### (How to set)

- Input the Injector duty cycle or duration adjustment value to the corresponding load and rpm points.

Airflow Hot Wire(V)	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000	7500	8000
1000	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
1200	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
1400	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
1600	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
1800	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2000	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2200	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2400	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2600	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2800	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
3000	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
3200	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
3400	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
3600	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
3800	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4000	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4200	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4400	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4600	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4800	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
5000	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

Adjustment rate: %  
 Input range: -80~100, 0.5% increment  
 Adjustment Duration: ms  
 Input range: -20~20ms, 0.02 increment

### Acceleration Injector Adjustment Map

- This map is used to smooth out the fuel enrichment during quick acceleration, by inputting the injector duty cycle or duration adjustment value, and the adjustment duration time.
- This feature will be activated when the unit detects a rapid throttle opening and be active for the set adjustment duration time.

#### (How to set)

- Input the Injector duty cycle or duration adjustment value to the corresponding throttle rate and rpm points.
- Input the adjustment decrease rate per rpm points. When this feature makes the inputted adjustment, it take the inputted decrease time to gradually return to normal setting.

Change Scale	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000	7500	8000
1	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
4	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
6	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
10	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
15	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
20	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
25	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
30	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
40	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
50	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
60	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
70	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
80	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
90	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
100	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
150	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
1000	20	20	20	20	20	20	20	20	20	20	20	20	20	20	20

Adjustment rate: %  
 Input range: -80~100, 0.5% increment  
 Adjustment Duration: ms  
 Input range: -20~20ms, 0.02 increment  
 Decrease rate: ms  
 Input range: 0.5~20ms, 0.5 increment

## 11. About Map and Setting

### Anti Engine Stall Setting

- This feature is used to prevent engine stall caused by turbo blow back to the airflow meter.
- Input the Throttle Position point which will activate this feature for the set amount of time. When the throttle position is below the inputted point, the e-manage Ultimate will recognize the accelerator as closed and will clamp the airflow meter signal going back to ECU.

(How to set)

- Input the airflow meter signal clamp voltage (or frequency) in each rpm range.
  - Input the throttle position activation value. This feature will activate when the unit detect the throttle position below the set value.
  - Input the activation duration time. This is the time it will take for this feature to turn off and go back to normal setting.
- \* If the throttle value is set to 1%, this feature will only activate only when the throttle is completely closed.
- \* If the throttle value is set to 0%, this feature will not activate.
- \* If the time value is set to 0 "--" will be displayed, and this feature will be active while the throttle and rpm conditions are met.

rpm	500	550	600	650	700	800	900	950	1000	1100	1150	1200	1300	1350	1400	1500
Clamp	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00

Throttle Position: %

Input range: 0 ~ 10%, 1% increment

Time: s

Input range: 0 ~ 5sec, 0.2sec increment

RPM: rpm

Input range: 500 ~ 16000rpm, 50rpm increment

Clamp Value: v or Hz (automatically set depending on the equipped sensor)

Input range: 0 ~5v, 0.02v increment (hot wire, flap type airflow meter, or pressure)

Input range: 0 ~ 3150Hz, 2Hz increment (Karman Vortex type airflow meter)

## 8. Parameter Setting

### Throttle

- This section is used to set the minimum and maximum voltage of the TPS signal.

(How to set)

Turn the ignition key to "ON" position (without engine running) and fully depress the accelerator to set the MIN and MAX voltage. The system will automatically detect the minimum and maximum voltage and will set the 0~100% throttle range. This can also be done while the engine is running to confirm setting.

Normal Type - Voltage increases as the accelerator is depressed.

Reverse Type - Voltage decreases as the accelerator is depressed.

This window will display the current voltage and the throttle position 0~100%

Manual Setting  
Place a check mark on these boxes to manually set the throttle setting. This will disable the auto detect. Input the desired voltages for "MIN" and "MAX" (Input range) 0.00~5.00V, 0.01 increment

Voltage at fully closed will display.  
\* MIN will be the voltage that was automatically detected.

Voltage at fully opened will display.  
\* MAX will be the voltage that was automatically detected.

### IMPORTANT

- When setting the throttle while the engine is running, be sure not to over rev the engine
- This setting will not program on a vehicle that does not have a throttle position signal, or vehicle with minimum and maximum switch only.

## 8. Parameter Setting

### CH Setting

- This section is used to configure the optional channels for "Water Temp/Knock Signal", "Intake Temp/Knock signal", "Airflow Meter 2/VTEC Output", "Analog Input and "Analog Output".
- The optional channels are Pin # 14,31,32, 37, and 38 on the e-manage Ultimate harness. See the Harness Diagram in the Installation Manual. Depending on what these pins are connected to, these channels must be activated in this window.

Pin # 32 and 38 in Connector C are configured in these sections.

- When connecting Water temp and/or Intake temp sensor, place a check mark in the box and select the sensor Type.
- The Unit can also use these temp sensor signal to activate a relay for a device. Enter the relay conditions to activate a device.
- Output signal wire can be activated in the I/J channel setting.
- Input range: 0° ~200°, 1° increment

To monitor knock sensor signal in the Real Time Display, set this section and select the sensor type.

- Input the frequency of the knock sensor when using the non-resonant type sensor.

This section will configure the Pin # 14 in Connector B.

- When the Engine type is selected, this section will be set automatically. If the input signal is changed make the necessary setting.
- Pin# 14 can be used for Second Airflow meter, or for auxiliary output signal for Auxiliary Map to control VTEC or relays. (Can be used for O2 sensor adaptor)

These sections will configure the Pin # 31, and 37 to be used for the "Analog Output Setting". Select the type of signal that is inputted and outputted.

### IMPORTANT

- If Water and Intake Temp are selected Knock 1 & 2 cannot be used.

## 11. About Maps and Setting

### Boost Limiter Cut Setting

- This feature can eliminate the factory boost limiter by clamping the airflow meter, or pressure sensor output signal to the ecu at the value right before ecu recognizes as the limit. Since the ecu would not recognize the amount of increase in airflow above the clamped value, it is necessary to make proper fuel compensation in the I/J map.
- \* For the vehicles equipped with airflow meter which uses a pressure sensor to activate the boost limiter, such as ER34, FC3S, and most Subaru, this feature will not eliminate the boost cut. Use the "Analog Output Setting" to eliminate the factory boost cut.

### (How to set)

- Monitor the airflow meter signal and rpm of when the boost cut occurs in the data log feature. Input the airflow meter clamp value right before the cut occurs in each rpm points.

rpm	500	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000	7500	8000
Clamp	5.00	5.00	5.00	5.00	5.00	5.00	5.00	5.00	5.00	5.00	5.00	5.00	5.00	5.00	5.00	5.00

RPM: rpm

Input range: 500 ~ 16000rpm, 50rpm increment

Clamp Value: v or Hz (automatically set depending on the equipped sensor)

Input range: 0 ~5v, 0.02v increment (hot wire, flap type airflow meter, or pressure)

Input range: 0 ~ 3150Hz, 2Hz increment (Karman Vortex type airflow meter)

### CAUTION

- When the airflow signal is clamped, ecu would not recognize the amount of increase in airflow above the clamped value, it is necessary to make proper fuel compensation in the I/J map.

## 11. About Maps and Setting

### Airflow Adjustment Map

- The signal from the Airflow meter (or pressure sensor, Karman vortex sensor) calculates the amount of intake airflow. The values inputted in this map alters the output signal going to the ecu.
- When a positive numbers are inputted, e-manage Ultimate sends a signal to the ecu telling there are more airflow than it actually are. Making the ecu inject more fuel and advance the ignition timing. (Since ecu thinks there are more airflow, it reads higher part of the fuel and ignition map)
- When a negative numbers are inputted, e-manage Ultimate sends a signal to the ecu telling there are less airflow than it actually are. Making the ecu inject less fuel and retarding the ignition timing. (since ecu thinks there are less airflow, it reads lower part of the fuel and ignition map)

#### (How to set)

- Input adjustment value to the corresponding load and rpm points.

Adjustment value: %  
Input range: -100~100%, 0.5 increment

### Airflow Output Map

- This map is used when the factory airflow meter is removed. By using a pressure sensor or throttle sensor signal, input the airflow signal which would be sent to ecu at each rpm points. This map will provide the ecu the airflow meter signal it requires.

#### (How to set)

- Input the Airflow output value to the corresponding load and rpm points.

Adjustment value: V, Hz  
Input range: 0~5V, 0.02V increment  
Input range: 0~3150HZ, 2Hz increment

### IMPORTANT

- Airflow Adjustment Map and Airflow Output Map can not be used at the same time.

## 8. Parameter Setting

### Front Panel

This section is used to configure the "DIP SWITCH", "OPTION 1&2", SWITCH, SERIAL, on the front panel of the e-manage Ultimate unit.

Select the sensor type or switches that are connected to the OPTION 1&2 port from the pull down menu.

#### Pull down menu items

- GReddy Pressure Sensor** •••• This sensor signal can be used as the load value for the map instead of factory sensor. (Used if the application exceeds the capacity of the factory sensor)
- GReddy Temp Sensor** ••••• This sensor can be used to monitor water, intake, and/or oil temp.
- A/F Sensor** •••••••••• This Sensor can be used for the Target Map and to monitor the air/fuel ratio in the Data Log feature.
- Multi Switching System** ••••• By linking the e-manage Ultimate to Multi Switching System, the e-manage can adjust the ignition timing when the Multi Switching System activates the optional output.
- External Switch** ••••••••• Switch can be used to start and stop the data logger or for ignition cut for launch control.
- Factory Pressure Sensor** ••••• By selecting the sensor type, pressure can be monitored in the data log feature.

Select the GReddy Warning Meter that is connected to the serial port to monitor in the data log feature.

The Active LED can be used as a warning light by setting the rpm and by selecting the desired input value.  
"and": Both RPM and the selected input condition must meet the set conditions for the warning to come on.  
"or" : Either rpm or the selected input condition must meet the set conditions for the warning to come on.

RPM  
Input range: 0~16000rpm, 1 rpm increment

Input signals  
Select from the input signal menu to activate the warning feature.

The dip switches on the front panel can be configured in this section. 2 different Injector Adjustment Map and Ignition adjustment map can be programmed and selected by this switch. Primary and secondary injectors as well as leading and trailing ignition can be separated in these 4 settings on rotary engines.  
Setup each of the dip switches from the pull down menu.

## 8. Parameter Setting

### A/F Target

- This section is used to setup the system for the "A/F Target Map".

The screenshot shows the following parameters and their callout descriptions:

- Affected Map:** [I/J Adjustment Map] - Select the map that A/F Target Map would program.
- Water Temp:** 80 - 95 C - Set the Water Temp condition of when the feedback would be activated. Input range: 30~110C°
- Throttle Position:** 90 % - Set the Throttle Position condition of when the feedback would be activated. Input range: 0~100%
- Start Time:** 120 Sec - Set the warm up time of the installed A/F sensor. During this time, the A/F feedback will not function. \*Please check with the installed A/F sensor manual for proper warm up time. Input range: 0~600sec
- Feedback Cycle:** 200 ms - Input the feedback correction cycle time. shorter the time the faster it will reach the target, but if it is too fast, the correction will be inconsistent. Input range: 20~300ms
- Feedback Amount:** 0.5 % - Input the feedback correction value per cycle. Higher the value, faster it will reach the target, but if the value is too high, the correction will be inconsistent. Input range: 0.5~5%

## 11. About Maps and Setting

### About Map Scale

- The scale can be changed in each of the maps.

(How to set)

- Click on the "Change Scale" button to release the lock.
- Once it is unlocked, the blue highlighted area will be clear, and will be adjustable by "Page up", "page down" key or manually inputting a value.

The screenshot shows the "Airflow Adjustment Map" interface. A blue arrow points to the "Change Scale" button. The table below represents the data shown in the map:

	500	1000	1500	2000	2500	3000	3500	4000	4500	500
2.00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2.20	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2.40	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2.60	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
2.80	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
3.00	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
3.20	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
3.40	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
3.60	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0

- The "0" within the maps are represented as factory ecu setting (no adjustment made).

RPM: rpm

Input range: 0 ~ 16000rpm, 50rpm increment

Load columns: V, Hz, Absolute pressure value (kPa, kg/cm2, mmHg, PSI)

Relative pressure value (kPa, kg/cm2, mmHg, PSI)

The Load value is automatically set when the airflow meter type is selected in the "Vehicle" setting. When the unit is changed in the "Unit" menu, the value will be set to it's closest value.

Input range: 0 ~ 5v, 0.02v increment (hot wire, flap type airflow meter, or pressure : V)


Input range: 0 ~ 3150Hz, 2Hz increment (Karman Vortex type airflow meter : Hz)

Input range: 0 ~5v, 0.02v increment (GReddy pressure sensor : V)

## 11. About Maps and Setting


### About Map Tree

- Map Tree will display the activated maps in the window.



### Popup Menu

Right click to open the popup menu at any time.




## 8. Parameter Setting

### I/J

- This section is used to configure individual injector output channels.
- The open injector channels can be used for sub injectors, NVCS, or activate relays.
- \* When the engine type is selected in the "Vehicle" section, the number of injector channels used and injector size will automatically set.

### Configuring Main Injectors



Set the number of Injector channels being used for main indicators.

\* # of output can be changed to convert group injection to sequential injection

Activate the I/J output channels for the I/J Adj. Map they are used for. I/J output CH are used if adding and trimming (+/-) fuel in the map.

Set to "+ / -" to trim and add fuel in the I/J Adj map and "+ only" for add only. Default setting is "+ / -". Select the cell and right click to display the menu, left click to select.

This section is used to configure the upgraded injectors. Input the upgraded injector size and it's Lag Time.


\* Make sure to use the same type of injectors as factory injectors. (Same resistance)

\* Primary and secondary injectors can be configured separately for rotary engines.

### Changing Injector Channels

Vehicles with simultaneous and grouped injection that has cam and crank angle signal can be changed to sequential injection by configuring the input and output signal.

To change the injector channels, set the output channel number, activate the each channel and set the injection timing.



Select the number of output channels used.

Set the injection timing of the added channels from the menu. (select the cell and right click to view menu)

Reference signal

Altered timing

This shows retarding 180° of the CH1 signal for CH4.

## 8. Parameter Setting

### When using these channels for other features.

- The open injector channels can be used for NVCS, or to activate relays for Water temp, Intake temp, and/or warning.

CH	Type	Map1	Map2	Type	Timing
CH-1	+ / -	1			1-0
CH-2	+ / -	2			2-0
CH-3	+ / -	3			1-180
CH-4	+ / -	4			
CH-5	Sub I/J				
CH-6					
CH-A					
CH-B					

Configure the channels by selecting the item from the menu. Select the cell and right click to view the menu, and left click to select.

### IMPORTANT

- When using the channels to activate relays, "Front Panel" and "CH Setting" must be configured.
- When using the channels to control NVCS, make sure that the channel wires are connected.

### Sub Injectors

When sub injector feature is selected, the "RPM" will be automatically selected as a reference signal type.

When using same number of sub injector as main injectors, they can be synchronized with the factory injection order.

# of Input: 2  
# of Output: 4

CH	Type	Map1	Map2	Type	Timing
CH-1	+ / -	1			1-0
CH-2	+ / -	2			2-0
CH-3	+ / -	3			1-180
CH-4	+ / -	4			
CH-5	Sub I/J			CH-1	
CH-6	Sub I/J			CH-2	RPM
CH-A	Sub I/J			CH-3	CH-1
CH-B	Sub I/J			CH-4	CH-2


RPM: Sub injectors will inject once every 2 rpm pulse signal. On 4 cylinder, they will inject twice every 2 rev. and 3 times on 6 cylinder.

CH-#: Sub injectors will inject at the same time as the selected channel.

\* Right click to view this menu, and left click to select.

## 10. About Tool Bar

### Tool Bar Description



### Menu

- New File (Ctrl+N)
- Open (Ctrl+O)
- Save (Ctrl+S)
- Print (Ctrl+P)

### Edit

- Cut (Ctrl+X)
- Copy (Ctrl+C)
- Paste (Ctrl+V)
- Undo (Ctrl+Z)
- Redo (Ctrl+Y)
- Interpolate

### Setting

- Map Tree (Ctrl+A)
- Parameter Setting

### Option


- Map Trace setting (Ctrl+M)
- Data Logger (Ctrl+T)

### Communication

- Import Data (Ctrl+R)
- Compare Data
- Export Data (Ctrl+W)

## 9. Parameter Setting

### Communication




- Real Time Communication  
Select to communicate with e-manage Ultimate at real time.
- Import Data (R) Ctrl+R  
To import data from e-manage Ultimate on to the desk top.
- Compare Data  
To compare the data in the e-manage Ultimate with the data on the desk top.
- Export Data (W) Ctrl+W  
To export data to e-manage Ultimate from desk top.
- Main Unit Update  
To update the E-manage Ultimate main unit.

### Help (H)



- Version Information  
To check the current software and main unit version type.



- Software version type.
- e-manage Ultimate main unit firmware version.
- e-manage Ultimate main unit update file version.

### Communication Status Indicator

The e-manage mark indicator in the top right corner will show the current online status.




- OFF LINE ······ Steady Yellow
- ON LINE ······ Steady Green
- ON LINE Communicating at real time ······ Flashing Green
- ON LINE Recording Data ······ Steady Red

## 8. Parameter Setting

### Ignition

#### Channel Configuration

- When the engine type is selected in the "Vehicle" setting the number of the ignition input and output channels is automatically set.
- In this section each ignition input and output channels can be configured.
- Distributer and group ignition type engines can be converted to individual ignition system by using cam and crank angle signals with necessary ignition system modifications and wiring.




Make the necessary changes by selecting the number of input and output CH numbers.

Activate the IGN output channels for the IGN Adj. Map they are used for. Right click to view the menu and left click to select.

#### Ignition Cut Feature

- This section can be used to configure the ignition cut feature to set a rev limiter at various conditions. (This feature will not eliminate the factory rev limiter. See Rev Limiter Cut Setting)
- Set the "Start" rpm for launch control. When there are no vehicle speed signal and throttle is open above the set %, the ignition cut will be activated.
- "IGN cut rpm" sets the max rev limit, and "Shift Up" will prevent over rev while power shifting using a switch.



Input the start rev cut rpm. This will only activate only when e-manage does not detect vehicle speed signal and throttle position is above set value in "Throttle Position".  
Input range: 0~9999rpm 1 rpm increment

Input the max rev limit rpm. This will not eliminate the factory rev cut. Input range: 0~9999rpm 1 rpm increment

Input the rpm limit while shifting up. (power shifting)  
Input range: 0~9999rpm 1 rpm increment

Select the switch used to activate the "Shift Up" ign. cut. The switch must be configured in the "Front Panel" and connected to the Option 1 or 2 Port. Switch can be clutch switch or shift up switch on a sequential transmission.

Ignition cut will activate when throttle position exceed above the input throttle position % value.  
Input range: 50~100%, 1% increment

Ignition timing can be adjusted while the ignition cut is activated. Place a check mark in the boxes and input the adjustment value.

Input the number of vehicle speed signal pulse it take to detect vehicle movement and to cancel the start rev cut to normal max rev limit.

### IMPORTANT

- make to set the "Shift Up" rpm value is lower than "IGN cut rpm".

## 8. Parameter Setting

### Trace

- This section will configure the map trace features.
- This feature can highlight the cells in the opened maps to show the current cells being read.


There are two selectable cursor sizes. When 4 cursor is selected, the current location will highlight in the color selected in "MAIN". The cells that made the correction will be highlight in the color selected in "SUB".

The trace can be set to highlight the cells for 1 sec, 3 sec, 10sec or continuous.

Color 1 , Color 2, and Log Trace color can be customized. Click on the cell to view the color chart.


## 9. About Menu Bar

### View (V)



- Tool Bar (T)  
Click to show or hide the Tool Bar.
- Map Tree (A) Ctrl+A  
Click or press Ctrl-A to show or hide Map Tree.
- Status Bar (S)  
Click to show or hide the Status Bar.
- Window  
Select to view the maps tiled or cascade.


### Unit



Select the desired units for the following signals for be displayed and used in the maps.

- Relative Pressure  
Select from x100kPa, kg/cm2, mmHg, PSI
- Absolute Pressure  
Select from x100kPa, kg/cm2, mmHg, PSI  
If the Relative Pressure Conversion is selected, the absolute pressure will be displayed like the relative pressure value. (like a boost gauge display)
- Temp  
Select from °C (Celsius) or °F (Fahrenheit)
- Injector Adjustment map  
Select from Duty cycle (%), or Duration (msec)
- Rev Limiter map  
Select from Duty cycle (%), or Duration (msec)
- Sub Injector map  
Select from Duty cycle (%), or Duration (msec)
- Ignition Adjustment map  
Currently, ignition adj. value only can be selected.  
In the future the actual ignition timing can be inputted.


### Logger (O)




- Data Logger  
Select to display the data log feature.
- Map Trace  
Select to start the map trace feature.

## 9. About Menu Bar

### File (F)



### Edit (E)




- **Interpolate-4corners**  
Select and highlight few cell in the map and select "Interpolate-4corners" to interpolate between 4 corners.
- **Interpolate-Rows**  
Select and highlight few cells in the map and select "Interpolate-Rows" to interpolate horizontally.
- **Interpolate-Columns**  
Select and highlight few cells in the map and select "Interpolate-Columns" to interpolate vertically.

## 8. Parameter Setting

### Map Select

- This section is used to activate the desired features and to set the password to lock them.
- Place check marks on the features to activate.




### Security Setting


- Each maps can be locked to prevent unwanted tampering.
- The settings can also be pass word protected.

### (How to set)

To Lock ••• Click on the green unlocked icon. Icon will turn to red (locked icon).  
To Unlock •• Click on the red locked icon. Icon will turn to green (unlocked icon).



### Password Protect



## 8. Parameter Setting

### Main Logger

- The e-manage Ultimate unit has a built in data logging features that can record up to 8 different input signals up to 1000 minutes without having PC connected.
- This section is used to configure the main unit data logger feature.
- This feature can be activated by the Remote Switching System or external switch connected to Option 1 or 2 in the front panel. The Option port must be configured in the "Front Panel" setting for the switch to work.

Cycle: 20 ms Rec. Time 10.00 minutes  
 Switch Sel: Switch 2

1. Engine Speed(rpm)  
 2. I/J Input Duty cycle  
 3. I/J Output Duration  
 4. Airflow Input(v)  
 5. Auxiliary Output  
 6. A/F Meter(0-5v) 2  
 7. Throttle Opening Rate  
 8. I/J Output Duty cycle

Select the sampling cycle from pull down menu. 20,50,100,200,500, or 1000ms  
 Maximum record time will display. Time will vary depending on the recording cycle. 10~500 minutes  
 Select the switch used to activate the main unit logger  
 Select the data to record from the menu. Click on the icon to view the menu.

Sampling Cycle / Recording Time

ms	minutes
20	10.00
50	25.00
100	50.00
200	100.00
500	250.00
1000	500.00

## 8. Parameter Setting

### A/T Shift

- This section is used to prevent knock during shift up and down on automatic transmission equipped vehicle by adjusting the ignition timing.
- This feature also can be used to minimize shock during shifting up and down.

rpm Condition: 5000 above rpm  
 T.P. Condition: 90 above %  
 Shift-up Condition: 500 rpm/50ms  
 Shift-up Adj. value: 0.0 Time: 20 ms  
 Shift-down Condition: 500 rpm/50ms  
 Shift-down Adj. value: 0.0 Time: 20 ms

Input the rpm condition to activate this feature. Input Range: 0 ~ 800rpm, 50rpm increment  
 Input the Throttle condition to activate this feature. Input Range: 0 ~ 100%, 1% increment  
 Input the rpm value per 50ms to detect the shift change. e-manage will detect the rpm change due to shift up or down. This setting will set the sensitivity of the detection. Input Range: 10 ~ 500rpm, 10rpm increment  
 Input the return time of the adjustment back to 0. The adjustment will return to normal after the inputted time. Input Range: 0 ~ 50msec, 1msec increment  
 Input the ignition adjustment amount for shift up and shift down. When the above set conditions are met, this feature will adjust the ignition timing for the set amount of time. Input Range: 0 ~ 20°, 1° increment